HOW TO MEASURE A BUCKET



Width of the bucket
Outer dimensions



Depth of the bucket
The bucket is placed vertically, and measured from the front, and in

A B
C D



Bucket height
Total height in the back



Bucket hight front
The bucket is placed vertically, and measured from the front and down

Hole spacing (E) and diameter (Ø) measured with calipers



The thickness is measured with a caliper